

~ Pax Tip ~

FLAWLESS CUTS ON PLYWOOD

For table saws:

- Install a zero-clearance table insert to reduce chip out
- Good face of material should be up.
- Raise the blade at least 2" above material. The teeth of the blade impact the sheet almost straight down.
- Use a minimum of 80 tooth blade designed for sheet goods.
- Keep blades sharp and clean.

For handheld circular saws:

- Good face of the material should be down, circular saw cut from the "bottom-up".
- Use a thin-kerf general purpose blade with at least 40 teeth.
- Keep blades sharp and clean