

~ Pax Tip ~

ROUTER BASICS

- Before using the router on your work piece, make a test pass on a scrap piece of wood to insure the bit is set to the proper depth
- Start the router with the bit away from the work piece, then gradually move the router into the material
- Pulling the router across the material rather than pushing the tool will provide smoother results
- Clamp your project to the work surface or use a router mat to hold the material securely before routing
- Always wear safety glasses