

*~ Pax Tip ~*

## **A GUIDE TO SELECTING THE HEIGHT OF STUDENT CHAIRS AND STOOLS**

As a rule of thumb, chairs or stools should be ten to eleven inches below the top of the work surface. Example — for a work surface that is thirty-nine inches high, chairs and stools should be twenty-eight to twenty-nine inches high.